

OPERATOR'S MANUAL



N72270-01

Table of Contents

Introduction	3
Installing Monitor	4
Identifying Monitor Switches	5
Home Screen - Operation Overview	5
Clutch In Motion Indicator	5
Home Screen - Operation Overview	6
Startup	7
Power On	7
Power Off	7
Sensor Installation	8
Installation Precautions	8
Installation Procedure	9
Monitor Settings	11
Navigating Settings Screens	11
Speed Settings	11
Wheel Pulses Per 400 Feet (PP400)	13
PP400 Math Calculation	13
Speed Calibration	14
Shaft and Fan Settings	15
Tank Not In Use	15
Rate Setting	16
Settings Menu Chart - Ground Drive	17
Alarms	18
Introduction	18
Nuisance Shaft Alarm	18
"In Motion" Notification	19
Low Fan Alarms	19
Area Display	20
Resetting Area	20
Rate Calibration	21
Actual Sample	22
Displayed Rates	25
Sensor Replacement	26
Sensor Gap Settings	27
Reed Switch Sensors	27
Variable Reluctance Sensors	27
Trouble Shooting Guide	28
Checking Harness	28
Checking Sensors	28
Checking Blockage System	28
Diagnostics	28
Updating Software	29
Calibration Chart - Imperial	30
Calibration Chart - Metric	33

Introduction

The monitor features an easy to use Touch Screen operation. The monitor utilizes a multiplexed data communication system to monitor the functions of the Air Cart. In the multiplexed system, all sensors communicate with the monitor on the same three wires.

The system can monitor and display status of the following functions:

- Fan speed (up to 3)
- · Ground speed
- Shaft speeds (up to 4)
- Bin levels (up to 4)
- Flow Blockage (up to 192 runs)

An audio alarm will sound upon detection of: low or high fan speed, low or high shaft speed, low bin level and failure of sensors. Also, loss of flow in any runs that are being monitored with Blockage Modules will generate alarms. Audio alarms persist until the alarm condition is removed or until the alarm is acknowledged by the operator by pressing the appropriate soft key.

In addition, the monitor can determine and display:

- Field Area
- Total Area
- Application Rate (weight per unit area)

The monitor allows the following settings to be changed:

- High and Low fan speed alarm point
- High and Low shaft speed alarm point for 4 shafts
- Ground speed pulses per 400 ft and pulses per revolution
- · Pulses per revolution of fans and 4 meter shafts
- Low bin alarm for 4 bins
- The number of Blockage Modules that are connected to the monitor
- The width of the implement
- Imperial or metric units

The settings listed above, as well as field and accumulated areas are stored in nonvolatile memory. This means that the information is retained even when power is disconnected.

The monitor has one tractor harness attached to it. The Tractor harness has a power plug that connects to the tractor power supply and a three pin plug that brings power and communications to the remote sensors through the main harness. The Tractor harness also has a four pin plug for optional radar or GPS connection.



MONITOR - N72101



CLUTCH SWITCHES

Installing Monitor

- Locate monitor and clutch switch in a convenient location in cab.
- Plug Monitor power cable directly to a 12V power plug / power bar in cab.
- Connect Clutch Switch power cables directly to a 12V battery.
 - White or Red wires **positive**.
 - Black wires negative.
- Route cable harness to seeding tool and Air Cart. Ensure cables clear any pinch points (i.e. tractor articulation point, hitch point, etc.)
- Program monitor as described in *System Installation* and *Monitor Programming* Sections.

- Note: Locate monitor, power and ground wires away from radio and antenna if tractor is so equipped.
- Note: Do not connect monitor or clutch switch directly to starter switch.



Identifying Monitor Switches

The five keys on the monitor face are used for controlling the monitor.

- Home Key Used to return to Main screen.
- Menu Key Used to access Main Settings Menu.
- **Up Key** No function attached to this key.
- **Down Key** No function attached to this key.
- Back Key No function attached to this key.
- Note: Monitor will show "communication errors" if the system installation (Sensor Learn Mode) was not completed. See Sensor Installation.



Home Screen - Operation Overview

Clutch In Motion Indicator

When Clutch is OFF the indicator will be displayed as

and all functions associated with the meter shafts will display OFF or have a zero count.

When Clutch is ON the indicator will be displayed as and all functions associated with the meter shafts will display their application.

Note: The monitor also emits a double beep whenever the "In Motion" condition becomes true or false.

Home Screen Overview continued on next page.





Monitor



Home Screen - Operation Overview

Monitor

Startup

Power On

Toggle the Power switch to turn the monitor on.

When the unit is turned on, the following display sequence takes place:

• ELITE is displayed while the LOUP bar loads.

This Splash Screen is displayed for a short time – long enough to go through the system startup and wakeup all of the sensors (approximately 3 seconds).

- If any sensors are found, the monitor proceeds to the "Operating" screen
- If no sensors are found, the monitor will display a "COMM ERROR ALARM".

Power Off

Toggle the Power switch to turn the monitor off.

Note: Monitor will show "communication errors" if the system installation (Sensor Learn Mode) was not completed. See Sensor Installation.



COMM ERROR ALARM Screen



Operating Screen

Sensor Installation

The installation procedure is required to configure the monitor to the sensors attached to it.

The operator may have to redo the installation if:

- 1) An extra tank is added to the Air Cart.
- 2) Replacing or adding sensors.
- 3) Replacing monitor with a new monitor.

Installation Precautions

- 1) During installation the monitor has a predetermined order in which it wants the sensors attached. The installer must be sure that the proper sensor is plugged in the proper sequence.
 - i.e. If during installation the installer plugs in the Front Shaft and Ground Speed sensors in the wrong order, the monitor would not know this. The monitor would interpret Front Shaft rpm from the Ground Speed shaft and vice versa.
- 2) There may be occasions when the operator will not have use of all the sensors.
 - i) During sensor installation when the monitor prompts for an unused sensor to be plugged in, the operator can press the SKIP THIS SENSOR key to skip over the sensor. The sensor will be assigned a disabled status. A sensor disabled by this method can only be enabled by repeating the installation procedure.

Note: Skip "LIFT SWITCH". The shaft ground speed sensor is connected to the clutch eliminating the need for a lift switch sensor.

- ii) During operation the operator can disable shaft sensors. When disabled, alarms for that shaft sensor and corresponding Bin Level sensor are ignored and no monitoring occurs.
- Blockage modules attached to the harness are handled differently than the sensors attached to the harness. See Assembly Section "Blockage Module".

Optical Sensors - the blockage modules **have to be unplugged from the harness** before sensor installation can be performed and are connected like the other sensors requested by the monitor during sensor installation. **Note:** Each monitor is unique to the sensors installed. If monitor is moved to another Air Cart it has to be reprogrammed to match the sensors.

Sensor Installation Order
Speed (Ground)
Lift Switch
Rate Calibration
Bin 1
Bin 2
Bin 3
Bin 4
Shaft 1
Shaft 2
Shaft 3
Shaft 4
Fan 1
Fan 2
Fan 3
Blockage Modules

Sensor Installation - Continued

Installation Procedure

- **Disconnect** all the sensors (3 pin connector) from the harness before turning monitor on.
- Note: Disconnect Hydraulic Rate Calibration at sensor connection indicated below.
- 1. Turn monitor on. With no sensors found, the monitor display "COMM ERROR ALARM" screen.

Press "CLEAR ALL ALARMS".

- The monitor will display the HOME screen. Press "MENU" key.
- 3. The monitor will display the SETTINGS screen.

Press "INSTALL SETUP" key.

Continued on next page.

Sensor Installation - Continued

Installation Procedure - Continued

- 4. The monitor will display the INSTALLATION screen. Press "LEARN NEW SYSTEM" key.
- 5. MANUAL LEARN CONFIRM screen will display.

Press "YES, LEARN NEW SYSTEM" key to start sensor learn sequence.

6. The display will indicate to install the SPEED sensor indicating that the speed sensor may now be connected. Connect the speed sensor.

The process is the same for rest of the sensors in the sequence.

- 7. When the monitor requests a sensor that **will not be used** in the configuration, press the "Skip this Sensor" key and the monitor will skip the sensor and advance to the next one in the sequence.
- **Note:** There are **12 Blockage Modules**. To skip past the blockage modules, press the "Skip this Type of Sensor" the monitor will skip all of the blockage modules and advance to the next type of sensor in the sequence.
- 8. When all sensors in the list have either been learned or skipped, the monitor will display "Manual Learn Complete". Press the OK key to complete sensor installation. The monitor will return to the SETTINGS screen.

To verify the installation, turn the monitor off, then turn it on again. The monitor will now proceed to the "Operating" screen with no comm errors.

Monitor Settings

Navigating Settings Screens

The settings screen contains all the configuration information required to tailor the monitoring capabilities to the installed system and user preferences. Only setting parameters that are relevant are displayed (i.e. if no Shaft 3 is installed, there will not be any Shaft 3 setting parameters made available).

Pressing the **MENU** key when in the "**HOME** Screen" enters this mode.

The "**SETTINGS** screen" will list all of the user adjustable parameters available.

Speed Settings

Located by selecting "**Menu**" and "**Speed Settings**", these settings control the type of speed input being used as well as calibrating the speed displayed on the main screen.

Select the "**Source**" button to change the type of Speed Input to use. There are four options Shaft Speed, Radar, GPS, and Simulated Speed.

1. SHAFT SPEED SENSOR: Uses the shaft rotation sensor located on the Cart to obtain ground speed. Unless otherwise configured this is also used as the lift switch for acres accumulation.

Note: The shaft ground speed sensor is connected to the clutch eliminating the need for a lift switch sensor.

2. RADAR SPEED: Uses the tractor radar for the source of ground speed. Depending on the implement configuration a lift switch may be needed when using radar, this is to ensure accurate accumulation of field acres.

3. GPS SPEED: Uses a GPS receiver for the source of ground speed. Depending on the configuration a lift switch may be needed when using GPS, this is to ensure accurate accumulation of field acres.

4. SIMULATED SPEED: Allows the user to enter a static speed into the monitor without any other speed source. For use in more unique conditions such as a GPS/Radar failure, or other troubleshooting.

Available when "**Simulated Speed**" is selected as the source. Use this field to enter the static speed of choice. The monitor will continually display this speed at all times until otherwise specified.

Important

The Ground Drive Air Cart only supports the Shaft Speed Sensor.

Speed Settings - Continued

Note: All Menu settings can be set before selecting "Exit & Save".

Pulses Per Revolution

Available when "Shaft Speed" is selected. Pulses per Rev (Revolution) are the number of magnets the Air Cart mounted speed sensor sees in one revolution of the shaft being monitored. Use keypad to set this number to **4** and select "**Exit & Save**".

Wheel Pulses Per 400FT

Available when "Shaft Speed" is selected. This is the ground speed calibration number for the Air Cart mounted speed sensor.

To change, refer to **PP400 Chart** on next page, select Tire Size on Cart and enter number into the keypad and select "**Exit & Save**".

Implement Width

Use keypad to set this number to the working width of seeding tool and select "**Exit & Save**".

Switch Setting

Select the "Raised Open" setting by pressing the Set Highest key.

Implement Switch

The implement switch is used to tell the monitor if a lift sensor is being used to determine when the Air Cart is seeding and when it's not. The lift switch sensor is used when shaft rotation cannot be used. (i.e. Radar and GPS)

Morris Air Carts use the shaft ground speed sensor which is connected to the clutch eliminating the need for a lift switch sensor.

Each button push toggles this setting between "Disabled" and "Enabled".

When a "Lift Switch" sensor is learned to the monitor, toggle the "Imp. Switch" button to "Enabled".

If shaft speed sensor is used set to "Enabled".

Lift Delay

When enabled, the Lift Delay specifies the seconds given to make a turn before an Alarm sounds. This value can range between 1 and 99 seconds.

Use keypad to set this number to 30.

Wheel Pulses Per 400 Feet (PP400)

The chart contains average PP400 values, for the tire options offered by Morris.

Note: Air Carts without brakes use a 63 tooth drive sprocket. Air Carts with brakes use a 64 tooth drive sprocket.

PP400 Math Calculation

To determine PP400 value, first determine the tire circumference as outlined below:

- The tire circumference should be checked under normal field conditions with tanks half full.
- Mark tire and starting point.
- Drive air cart 10 revolutions of tire.
- Mark ending point.
- Measure distance from starting point to ending point and divide by 10 to get the rolling circumference of the tire.

Note: The PP400 can also be determined using the speed calibration feature.

PP400 - Ground Drive				
Tire Size (Good-Year)	Tire Style	Rating	Pressure	PP400
800/65B32	1.00	172 48	15 psi	382
000/03H32	Lug	172 40	20 psi	381
No Brakes 800/65R32 Dual Wheels	Lug	172 A8	20 psi	381
Brakes 800/65R32 Dual Wheels	Lug	172 A8	20 psi	387
000/60B32	Lug	176 4 8	17 psi	356
900/001132	Lug		26 psi	351
710/70 R38	Lug	166 A8	36 psi	351
800/70R38 Dual Wheels	Lug	173 A8	20 psi	342
850/80R38 Dual Wheels	Lug	180 A8	15 psi	312
520/85R38 Dual Wheels	Lug	155 A8	20 psi	377

Formulas - Metric			
Monitor PP400 Setting:			
For 32" Rim = 2048.256/Tc			
For 38" Rim = 2048.256/Tc PP400 =			
Monitor PP400 Setting: BRAKES			
For 32" Rim = 2080.768/Tc			
For 38" Rim = 2080.768/Tc PP400 =			
Tc = Tire Circumference measured in meters			

Speed Calibration

If the operator does not know what the pulses per 400 feet should be, or, if more accuracy is desired for present levels of tire inflation or soil conditions, the monitor can be put into "Speed Calibration" mode, pulses will be counted while driving a specified distance.

To start the Pulse Counting Mode:

- 1. Measure and mark out 400 feet (121.92 m).
- 2. Select **SPEED SETTINGS** under the "Settings Menu".

Then select SPEED CALIBRATION.

3. Press **START CALIBRATION** to start the pulse count sequence.

Drive the marked distance and the monitor will count the number of pulses.

- 4. When the distance has been travelled, stop forward travel. Press the "Exit and Save" to save the new pulse count under the SPEED SETTINGS screen.
- 5. The new value will now be displayed under "Wheel Pulses Per 400 Feet" (PP400).
- To exit SPEED SETTINGS press the "Exit and Save" to save changes.
- Note: The monitor can accept PP400 values from 50 to 9999. Therefore, if the new count is less than 50, the existing count is not replaced. The monitor will state "Pulses Too Low" and display options to "Continue Driving" or "Cancel Calibration".

Shaft and Fan Settings

1. From the HOME screen press "MENU" key.

The monitor will display the SETTINGS screen.

Press "SHAFT & FAN SETTINGS" key.

2. The monitor will display the "SHAFT & FAN SETTINGS" screen. Starting with SHAFT 1.

Under Shaft 1 set:

• Status - Enabled and Rate Sensor - ON

Pressing the green arrow or red arrow to navigate through the sensors available.

3. Set **PULSES PER REV** to 4 and **HIGH RPM** to 150 and **LOW RPM** to 2

Repeat steps 2 and 3 for the other shafts.

Note: All Shaft & Fan settings can be set before selecting "Exit & Save".

To save changes press EXIT & SAVE.

The monitor will return to the SETTINGS screen.

4. Turning **Rate Sensor** OFF will close the pounds per rev icon and also the Home screen window for the shaft. The shaft will still be monitored for alarms.

Tank Not In Use

5. If a tank is not being used for an application switch the shaft Status to DISABLED. This will eliminate nuisance alarms.

Remember to Enable shaft when resuming use of tank.

Shaft and Fan Settings - Continued

Rate Setting

6. POUNDS PER REV is automatically set during the Rate Calibration procedure. This value can be manually edit under each shaft setting over-riding the saved setting from Rate Calibration. Once it is overwritten the Rate Calibration value cannot be retrieved. Therefore, it is recommended to keep a record of the Rate Calibration WT/REV value for each tank in a note pad for reference.

This value is used to calculate the Applied Rate and Tank Area Left display on the home screen.

Best practice is to perform a Rate Calibration to obtain an accurate WT/REV however, if a quick setting is required the Rate Charts at the end of this section can be used as an estimated value.

Note: Rate Calibration feature does not function on Carts not equipped with Hydraulic Rate Calibration. Manual entry from the charts is the only option on such Carts.

6	% 1	
SHAFT & FAN	SETTINGS	
SHAFT 1		
•	STATUS: ENABLED	RATE SENSOR: ON
PULSES PER REV: 4	HIGH RPM: 150	LOW RPM:
POUNDS PER REV: 2.07		BACK EXIT & SAVE

- 7. Set the Fans to:
 - PULSES PER REV to 2
 - HIGH RPM to 5000 and LOW RPM to 3000

To save changes press EXIT & SAVE.

The monitor will return to the SETTINGS screen.

Note: All Shaft & Fan settings can be set before selecting "Exit & Save".

7 AFT & FAN	SETTINGS	
FAN 1		
PULSES PER REV: 2	HIGH RPM: 5000	LOW RPM:
		BACK EXIT & SAVE

Settings Menu Chart - Ground	l Drive		
Install Setup			
Install New System	See "Sensor Installation"		
Add a Sensor	See "Sensor Repla	acement"	
Remove a Sensor	See "Sensor Repla	acement"	
Speed Settings			Important
Source	Set to "Shaft Spee	d"	Select "Exit and Save" in
Pulses Per Rev	Set to 4		each Menu Setting to save
Implement Switch	Enabled		changes.
Wheel Pulses Per 400 Feet _	See PP400 Chart		
Implement Width	Set to width of see	ding tool	
Lift Delay	30 seconds - Can b	be adjusted to	user preference.
Speed Calibration	See "Pulse Counti	ng Mode for	PP 400"
Switch Setting	ON _ Raised Oper	n _ press Set	Highest key
Shaft Settings			
Shaft 1, Shaft 2, Shaft 3 and S	Shaft 4		
Alarm Setting	Enabled (default)	Set to Disa	bled if tank is not in use.
Settings	Pulses Per Rev	Set to 4	
	High Alarm Point	150 rpm - (Can be adjusted to 200 for high rates.
	Low Alarm Point	2.0 rpm - C	an be adjusted to 1 rpm for low rates.
Fan Settings			
Pulses Per Rev	Set to 2		
Low Alarm Point	Set to 3000 rpm		
High Alarm Point	Set to 5000 rpm		
Blockage Module Settings			
Runs per Module Setup	Set individual Mod	ule number o	of Runs
Individual Runs Setup	Allows Runs to be	Enabled/Dis	abled
Blockage Module Test	See "Blockage Module Test"		
Blockage Calibration	See "Blockage Calibration"		
Display & Updates			
Brightness	50% (default)	Set as des	ired.
Volume	50% (default)	Set as des	ired.
Clock		Set as des	ired.
Units	Select Imperial or Metric		
System Update	Software Update		
	Factory Reset - Lo	cked to prev	ent accidental reset
	Unlock Reset - Loo	cked to preve	ent accidental reset

Note: Only setting parameters that are relevant are displayed (i.e. if no Shaft 3 is installed, there will not be any Shaft 3 setting parameters made available).

Alarms

Introduction

All configured sensors and various other operating conditions are continuously monitored. Alarms fall into one of the following three categories:

- **Sensor alarms** are alarms which are generated when information returned by a sensor exceeds the appropriate threshold.
- **Communication alarms** occur when a sensor repeatedly does not respond to attempts at communication.
- **System alarms** are for various other conditions that are found to be in fault.

When an alarm condition occurs, the monitor will beep repeatedly and an alarm screen will pop up indicating the fault condition.

The audio alarm and alarm screen persist until the alarm condition is fixed or until it is acknowledged by the operator. Follow the steps on the screen to fix or acknowledge the alarm.

After acknowledgement, the "Operating Screen" will be displayed with a flashing "Warning Symbol" indicatng unfixed alarms. Press the "Warning Symbol" to shown the "Active Alarm" window to view alarms.

When the alarm condition is corrected, the flashing "Warning Symbol" notification is removed from the "Operating Screen".

Nuisance Shaft Alarm

Low application rates of Canola may cause the seed shaft to rotate less than 2 rpm.

The low shaft rpm will cause the monitor to give a shaft alarm, since the shaft is rotating below the default alarm threshold of 2 rpm.

To avoid this nuisance alarm, change the seed shaft low rpm alarm setting to 1 rpm and change pulses to 1.

Note: Change the setting back to 2 rpm and 4 pulses when returning to higher application rates.

Alarm Screen

Alarm - Operating Screen

		ELITE
8 32 AM	Q 1	1 March 1997
ACTIVE ALARMS	•	
GENERAL ALARMS:	COMM ERRORS:	
SHAFT 2 LOW RPM BIN 1 EMPTY	NO COMM ERRORS	
		BACK

Alarms - Continued

"In Motion" Notification

The "In Motion" condition means that the monitor, based on ground speed and clutch state, considers that the system is supposed to be actively seeding.

The monitor emits a double beep whenever the "In Motion" condition becomes true or false. This condition is defined as *speed greater than 2 mph (3.2 Kph)* and *drive clutch engaged.*

- If ground speed is less than 2 mph (3.2 Kph) for more than 30 seconds the monitor will alarm and display "Should be Seeding".
- If ground speed is greater than 2 mph (3.2 Kph) for more than 30 seconds and clutch is not engaged the monitor will alarm and display "Clutch Switch is Off".
- 3. Certain alarms are inhibited when the "In Motion" condition is false. These are described elsewhere in this manual, but an example is whether to generate an alarm for a stopped shaft.

If a speed sensor is unavailable the metering shaft monitoring and associated functions will not display.

Low Fan Alarms

Low fan alarms are handled differently because a stopped fan can result in damage to the metering mechanics as unblown material accumulates. Low fan alarms cannot be acknowledged while the system is "in motion". Thus, if a low fan alarm occurs during active seeding, the user will **not be able** to silence the alarm but will need to stop the vehicle or disengage the clutch. When this happens, the monitor accepts it as an acknowledgement of the alarm, and an effective "automatic acknowledge" takes place, resulting in the beeper being silenced and the resumption of normal display with "Fan Low RPM" flashing in the alarm window.

Area Display

There are two area counters, field area and total area. They are both accumulated whenever the system "In Motion" condition is true. Area counts are stored in memory when the unit is turned off.

The area counts can be displayed on the "Operating Screen" as outlined in "Navigating the Operating Screen". The FIELD AREA and the TOTAL AREA are displayed to the nearest tenth of an acre (or hectare).

Resetting Area

To clear FIELD AREA and/or TOTAL AREA follow the steps below.

- From the "Operating Screen" press the desired function of "Field Area" or "Total Area".
- The monitor will ask "Are you sure?"
- Press the CANCEL key to leave area count and return to the "Operating Screen".

OR

Press the YES, CONFIRM key to clear area and return to the "Operating Screen".

Rate Calibration

The practice of doing a rate calibration is strongly recommended as it will confirm the **actual** amounts of product being metered.

The following procedure should be followed for every change of product.

- Ensure correct seed plates are installed.
- Fill tank 1/2 full and drive 600 1000 feet to compact product in the tanks.
- Select and install meter rate sprocket per Rate Chart.
- Set Flapper Valves to the "Calibration" position.
- Remove the metering chain from the transmissions that are **not** being checked.
- Open lower collector door at the bottom of the collector body.
- Hook the Rate Calibration Insert on collector bottom and rotate up into position. Secure in place with slide lock.
- Slide rate check box on the collector body.
- Engage hydraulic lever to run air cart.
- **Turn off fan** by switching selector valve (located in the fan supply line) to calibration position.
- **Prime metering wheels first** by using the primer switch to start and stop the meter drive. Allow the drive to run until material begins to fall through the collector body.

Note: Ensure the fan is not running.

- Empty material from rate check box and reinstall it on the same collector.
- The monitor can be relocated to the remote monitor location for ease of calibration. The 10 pin plug connects to the monitor.

Actual Sample

- See following page.
- Note: Rate Calibration feature does not function on Carts not equipped with Hydraulic Rate Calibration.

Important

Flapper Valves must be set to "CALIBRATION"

Double Shoot Shown

Rate Calibration - Continued

Actual Sample

Example: Calibrate Shaft 1.

- Note: Rate Calibration always displays four tanks even if the Cart only has two or three tanks.
- 1. From the HOME screen press the MENU key to enter the SETTINGS screen.

Press RATE SETTINGS.

2. The monitor will display the RATE SETTINGS screen.

Press RATE CALIBRATION key to enter function.

- Note: The "Rate Cal Num" is Factory set and can not be adjusted.
- 3. PRIME METER will be displayed, press the prime button it will turn green, then prime metering wheels as outlined on previous page.
- Note: Tapping "Prime Meter" a second time takes you directly to "Start". Only do this if meter wheels are already primed.
- 4. START will now be displayed:
 - a. Press and hold WT/REV area to bring up warning to RESET TANK CAL WEIGHT, select "Yes" to zero the Tank information.
 - b. Press the start button, then engage Hydraulic Calibration Motor by holding switch in ON position to begin CAL AREA count.
- Note: REVS must be cleared before taking a sample in order to have an accurate WT/REV calculation.

January 2022

Rate Calibration - Continued

Actual Sample - Continued

5. Release switch when desired Area count is reach on the monitor.

Remove the rate check box from the collector body.

Weigh the sample by using tarp straps to hook rate check box to spring scale.

- Note: Remember to subtract the weight of the rate check box from the total sample weight. Accuracy of sample is critical for actual application rate accuracy.
- 6. Press WEIGHT under the Tank being calibrated. Use the key pad to enter the value of the sample weight.
- 7. The Monitor automatically displays application rate under RATE.

Continued on next page...

CALIBRATION 5 SPEED PULSES: 381 CAL AREA= 0.12 857 60.0 TURN TO A MINIMUM OF .1 ACRE LOW RATES MINIMUM .5 ACRE CAL AREA IMP. WIDTH: TANK 1 TANK 2 TANK 3 TANK 4 WEIGHT: 14.40 WEIGHT: WEIGHT: 0.00 WEIGHT: 0.00 RATE: 0.0 RATE: 0.0 RATE: 0.0 RATE: 0.0 LBS/ACRE REVS: 4.5 WT./REV: (LBS/ACR LBS/ACRE REVS: 9.5 WT./REV: 0.0 REVS: 0.0 WT./REV: 0.0 REVS: 0.0 WT./REV: SAVE TANK 4 SAVE TANK 1 SAVE TANK 2 SAVE TANK 3

Rate Calibration - Continued

Actual Sample - Continued

- 8. To perform a second rate check:
 - a. Press and hold WT/REV area to bring up warning to RESET TANK CAL WEIGHT, by selecting "Yes" will zero the Tank information.
 - b. Press CLEAR CAL AREA to zero Cal Area.
 - c. Repeat steps 4 to 7.
- 9. Press SAVE TANK to retain value, before moving to next Tank.

Repeat steps 3 to 9 for eachTank.

10.Press BACK to return to RATE SETTINGS screen.

Under the RATE SETTINGS screen press EXIT & SAVE to save calibration rates and exit back to SETTINGS screen.

- 11. Check under the Shaft Settings to verify the WT/REV saved correctly from the Rate Calibration screen.
- 12. Replace the bottoms of the collectors. Place rate check box into storage bracket.
- Note: Upon "EXIT & SAVE" from the Rate Settings screen, the WT/REV from each tank gets automatically transferred to the appropriate shaft setting.

The WT/REV value can be manually edit under each shaft setting over-riding the saved setting, which then cannot be retrieved. Therefore, it is recommended to keep a record of the WT/REV for each tank in a note pad for reference.

Displayed Rates

There are two rates that can be displayed on the Home Screen:

 Applied Rate - This is calculated based on the Weight per Rev (WT/REV) saved for each Tank during Rate Calibration.

Best practice is to perform a Rate Calibration to obtain an accurate WT/REV however, if a quick setting is required the Rate Charts at the end of this section can be used as an estimated value.

- 2. Tank Area Left This is calculated based on the Weight per Rev (WT/REV) saved for each Tank during Rate Calibration and the weight entered for each Tank. This is meant to be used as a reference on remaining acres, not an actual. The exactness of this value is based on the accuracy of the Tank Weight and the WT/REV entered.
- Note: Rate Calibration feature does not function on Carts not equipped with Hydraulic Rate Calibration. Manual entry from the charts is the only option on such Carts.

Determine the product weight in each Tank by:

- 1. Get each tank capacity (V) from the Specification section, bushel (bu) for Imperial measurements or litre (I) for metric measurements.
- 2. Determine the density of product **(PD)** in pounds per bushel (lbs/bu) for Imperial measurements or kilograms per litre (kg/l) for metric measurements.

V = Tank Volume

3. Use formula below to get weight of each tank.

Tank Weight Formula

PD = Product Density

PD x V = Tank Weight

Enter Tank Weight for each shaft on Home screen.

- 1. Long Press on each Shaft Window to Reset the Tank Weight. This will prompt to enter a new Tank Weight for the corresponding Shaft.
- 2. The monitor will display a RESET TANK WEIGHT screen.

Press YES, CONFIRM key to enter function.

- 3. Enter tank weight and press enter.
- 4. Tank Area Left will now be displayed while seeding.

Tank Weight for each shaft will have to be reset each time the tanks are filled.

Sensor Replacement

The monitor will alarm the operator if there is a faulty sensor in the system by displaying a communication error for the sensor.

To replace a faulty sensor, follow the steps below.

Example: Replace Fan 1 sensor.

1. From the HOME screen press the MENU key to enter the SETTINGS screen.

Press INSTALL SETUP.

2. The monitor will display the INSTALLATION screen.

Press ADD A SENSOR key to enter function.

3. The monitor will display the sensor types available. For this illustration we will select FAN SENSOR.

Pressing the green arrow or red arrow will scroll through the sensors available.

Pressing ADD SENSOR will promote the monitor to search for new sensor. Plug new sensor into harness at this point.

- 4. Once the monitor acknowledges the new sensor, the monitor will display NEW SENSOR FOUND Press "Exit and Save" to accept sensor.
- The monitor will display FAN 1 SENSOR ADDED SUCCESSFULLY under Status confirming sensor installation. Press "HOME" to return to operating screen.
- Note: Sensors can also be removed from the system in the same manner by selecting the REMOVE A SENSOR choice from step 2.

Sensor Gap Settings

Reed Switch Sensors

These sensors are used on slowly revolving shafts, in this case the meters and ground speed.

Check the gap between the sensor and actuator.

A gap of .030 inch (0.76 mm) is recommended.

Variable Reluctance Sensors

These sensors are used on high speed shafts, in this case the fan.

Target to sensor gap is critical with these sensors.

A gap of .030 inch (0.76 mm) is recommended.

Trouble Shooting Guide

Most electronic problems are usually one of the following:

- Harness connections.
- Damaged harness wires.
- · Loose terminal in harness plug.
- Sensor to Actuator clearance.
- Defective sensor.

The monitor will alert the operator of these problems as a communication error.

Checking Harness

First, check for the obvious things like broken connections, loose terminals, insulation rubbed off and so forth.

· Check continuity of wires with ohm meter.

Checking Sensors

The best approach to testing a sensor is to substitute a suspected sensor with a known good one. If the problem goes away, the sensor is faulty. If it does not go away, it is faulty wiring.

Bin Level Sensors ensure there is no foreign material covering the optical sensor. Remove material with a cloth as not to damage lens.

Make sure sensor wires are not damaged.

Checking Blockage System

Check modules by performing a blockage module test on the monitor.

Optical sensors make sure the "optical eyes" are not coated with material or worn down. Remove material with a cloth as not to damage lens.

Pin sensors make sure there is no buildup of material on the pins. Remove material buildup with a knife and gently scraping away the material buildup.

Make sure sensor wires are not damaged.

Diagnostics

The Diagnostics screen can help in identifying issues with sensors, harnessing or other items. Status reports for Battery Voltage, Sensors Learned, MUX Communication speed and GPS Communication speed are displayed. Contact Loup Electronics if you need technical support.

Updating Software

Download software from www.morris-industries.com. The file downloaded will be in a .ZIP format and need to be extracted. When extracted you should see a folder titled "EliteUpdate" and within it the Elite software file. Copy the "EliteUpdate" folder to the root level of the USB drive.

Update Process

- 1. Insert the USB drive on the right had side of the Elite console.
- 2. Select "MENU DISPLAY & UPDATES SYSTEM **UPDATES - SOFTWARE UPDATE**"
- 3. Monitor should now show a popup window displaying the update file on the USB drive.
- 4. Select the new version to begin loading the software. When done loading the console will ask you to cycle power. Wait 10 seconds to ensure software download is complete.
- 5. Turn monitor off and remove USB drive. Wait 10 seconds and turn monitor on. Upon doing so the monitor will start with a blank screen and the keypad will pulse for a short period as it finished the update. The console will then boot into the newest version.
- 6. Confirm the monitor has been updated by checking the version number inside the main settings screen.

Calibration Chart - Imperial

פו אוי פסבבה הסוענ		חומר א המוער
SEED & INOCULAN	T SEED	FERTILIZER
x9///		1 5////////////////////////////////////
all and all and	2 3 3 x 3 x 5 5 6 1 8 9	* N 10 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1
	ぎ ちょう むょ むょ むょ むょ むょ むょ むょ むょ むょ	Ý N N N N N N N N
21 0.032 0.035 0.036 0.045 0.053	21 0.153 0.207 0.269 0.294 0.347 0.380 0.428 0.444 0.517 0.569	21 0.302 0.339 0.377 0.425 0.456
		22 0.316 0.356 0.395 0.445 0.478
		27 0 388 0 436 0 484 0 546 0 587
28 0 043 0 047 0 049 0 060 0 071	28 0 204 0 276 0 359 0 392 0 462 0 506 0 571 0 592 0 689 0 759	28 0 403 0 452 0 502 0 566 0 609
29 0.044 0.049 0.050 0.062 0.073	29 0.211 0.286 0.372 0.406 0.479 0.524 0.591 0.613 0.714 0.786	29 0.417 0.469 0.520 0.587 0.630
30 0.046 0.050 0.052 0.064 0.076	30 0.218 0.296 0.384 0.420 0.495 0.542 0.611 0.635 0.738 0.813	30 0.431 0.485 0.538 0.607 0.652
31 0.047 0.052 0.054 0.066 0.078	31 0.226 0.306 0.397 0.434 0.512 0.560 0.632 0.656 0.763 0.841	31 0.446 0.501 0.556 0.627 0.674
32 0.049 0.054 0.056 0.068 0.081	32 0.233 0.316 0.410 0.448 0.528 0.578 0.652 0.677 0.787 0.868	32 0.460 0.517 0.574 0.647 0.696
33 0.050 0.055 0.057 0.070 0.083	33 0.240 0.326 0.423 0.462 0.545 0.596 0.672 0.698 0.812 0.895	33 0.474 0.533 0.592 0.667 0.717
34 0.052 0.057 0.059 0.072 0.086	34 0.248 0.336 0.436 0.476 0.561 0.615 0.693 0.719 0.837 0.922	34 0.489 0.549 0.610 0.688 0.739
35 0.053 0.059 0.061 0.075 0.088	35 0.255 0.345 0.448 0.490 0.578 0.633 0.713 0.740 0.861 0.949	35 0.503 0.566 0.628 0.708 0.761
36 0.055 0.060 0.062 0.077 0.091	36 0.262 0.355 0.461 0.504 0.594 0.651 0.734 0.761 0.886 0.976	36 0.518 0.582 0.646 0.728 0.782
37 0.057 0.062 0.064 0.079 0.094	37 0.269 0.365 0.474 0.518 0.611 0.669 0.754 0.783 0.910 1.003	37 0.532 0.598 0.664 0.748 0.804
38 0.058 0.064 0.066 0.081 0.096	38 0.277 0.375 0.487 0.532 0.627 0.687 0.774 0.804 0.935 1.030	38 0.546 0.614 0.682 0.769 0.826
39 0.060 0.065 0.068 0.083 0.099	39 0.284 0.385 0.500 0.546 0.644 0.705 0.795 0.825 0.960 1.057	39 0.561 0.630 0.700 0.789 0.848
40 0.061 0.067 0.069 0.085 0.101		40 0.575 0.646 0.718 0.809 0.869
		43 0.618 0.693 0.712 0.670 0.935
46 0.070 0.077 0.080 0.098 0.116	46 0.335 0.454 0.589 0.644 0.759 0.831 0.937 0.973 1.132 1.247	46 0.661 0.743 0.825 0.930 1.000
47 0.072 0.079 0.082 0.100 0.119	47 0.342 0.464 0.602 0.658 0.776 0.850 0.958 0.994 1.156 1.274	47 0.676 0.760 0.843 0.951 1.022
48 0.073 0.081 0.083 0.102 0.121	48 0.350 0.474 0.615 0.672 0.792 0.868 0.978 1.015 1.181 1.301	48 0.690 0.776 0.861 0.971 1.043
49 0.075 0.082 0.085 0.104 0.124	49 0.357 0.484 0.628 0.686 0.809 0.886 0.998 1.036 1.206 1.329	49 0.704 0.792 0.879 0.991 1.065
50 0.076 0.084 0.087 0.107 0.126	50 0.364 0.493 0.641 0.700 0.825 0.904 1.019 1.058 1.230 1.356	50 0.719 0.808 0.897 1.011 1.087
51 0.078 0.086 0.089 0.109 0.129	51 0.371 0.503 0.653 0.714 0.842 0.922 1.039 1.079 1.255 1.383	51 0.733 0.824 0.915 1.032 1.109
52 0.079 0.087 0.090 0.111 0.131	52 0.379 0.513 0.666 0.728 0.858 0.940 1.060 1.100 1.279 1.410	52 0.748 0.840 0.933 1.052 1.130
53 0.081 0.089 0.092 0.113 0.134	53 0.386 0.523 0.679 0.742 0.875 0.958 1.080 1.121 1.304 1.437	53 0.762 0.857 0.951 1.072 1.152
54 0.083 0.091 0.094 0.115 0.137	54 0.393 0.533 0.692 0.756 0.892 0.976 1.100 1.142 1.329 1.464	54 0.776 0.873 0.969 1.092 1.174
55 0.084 0.092 0.095 0.117 0.139	55 0.401 0.543 0.705 0.770 0.908 0.994 1.121 1.163 1.353 1.491	55 0.791 0.889 0.987 1.112 1.195
56 0.086 0.094 0.097 0.119 0.142	56 0.408 0.553 0.717 0.784 0.925 1.012 1.141 1.184 1.378 1.518	56 0.805 0.905 1.005 1.133 1.217
57 0.087 0.096 0.099 0.122 0.144	57 0.415 0.562 0.730 0.798 0.941 1.030 1.162 1.206 1.402 1.545	57 0.820 0.921 1.023 1.153 1.239
58 0.089 0.097 0.101 0.124 0.147	58 0.422 0.572 0.743 0.812 0.958 1.048 1.182 1.227 1.427 1.573	58 0.834 0.937 1.041 1.173 1.261

Calibration Chart - Imperial			
	WT/REV (LBS./REV)		
SLOW SPEED DRIV	E DIRECT DRIVE	DIRECT DRIVE	
SEED & INOCULAN	T SEED	FERTILIZER	
NO NO N			
	\mathcal{S}'' \mathcal{S}'	N/ N/ K/ K/ K/ K/ K/	
	?// _* 0/ 0/ 0/ 0/ 0/ 0/ 0/ 0/ 0/ 0/ 0/ 0/ 0/ 0	$\mathcal{W}_{\star}^{\delta}$	
	59 0 430 0 582 0 756 0 826 0 974 1 066 1 202 1 248 1 452 1 600	59 0 848 0 953 1 059 1 193 1 282	
60 0.092 0.101 0.104 0.128 0.152	60 0.437 0.592 0.769 0.840 0.991 1.085 1.223 1.269 1.476 1.627	60 0.863 0.970 1.077 1.214 1.304	
61 0.093 0.102 0.106 0.130 0.154	61 0.444 0.602 0.781 0.854 1.007 1.103 1.243 1.290 1.501 1.654	61 0.877 0.986 1.095 1.234 1.326	
62 0.095 0.104 0.108 0.132 0.157	62 0.452 0.612 0.794 0.868 1.024 1.121 1.263 1.311 1.525 1.681	62 0.891 1.002 1.112 1.254 1.348	
63 0.096 0.106 0.109 0.134 0.159	63 0.459 0.622 0.807 0.882 1.040 1.139 1.284 1.333 1.550 1.708	63 0.906 1.018 1.130 1.274 1.369	
64 0.098 0.107 0.111 0.136 0.162	64 0.466 0.632 0.820 0.896 1.057 1.157 1.304 1.354 1.575 1.735	64 0.920 1.034 1.148 1.294 1.391	
65 0.099 0.109 0.113 0.139 0.164	65 0.473 0.641 0.833 0.910 1.073 1.175 1.325 1.375 1.599 1.762	65 0.935 1.050 1.166 1.315 1.413	
66 0.101 0.111 0.115 0.141 0.167	66 0.481 0.651 0.846 0.924 1.090 1.193 1.345 1.396 1.624 1.789	66 0.949 1.067 1.184 1.335 1.435	
67 0.102 0.113 0.116 0.143 0.169	67 0.488 0.661 0.858 0.938 1.106 1.211 1.365 1.417 1.648 1.817	67 0.963 1.083 1.202 1.355 1.456	
68 0.104 0.114 0.118 0.145 0.172	68 0.495 0.671 0.871 0.952 1.123 1.229 1.386 1.438 1.673 1.844	68 0.978 1.099 1.220 1.375 1.478	
69 0.105 0.116 0.120 0.147 0.174	69 0.503 0.681 0.884 0.966 1.139 1.247 1.406 1.459 1.698 1.871	69 0.992 1.115 1.238 1.396 1.500	
70 0.107 0.118 0.122 0.149 0.177	70 0.510 0.691 0.897 0.980 1.156 1.265 1.426 1.481 1.722 1.898	70 1.006 1.131 1.256 1.416 1.522	
71 0.109 0.119 0.123 0.151 0.180	71 0.517 0.701 0.910 0.994 1.172 1.283 1.447 1.502 1.747 1.925	71 1.021 1.147 1.274 1.436 1.543	
72 0.110 0.121 0.125 0.154 0.182	72 0.524 0.710 0.922 1.008 1.189 1.301 1.467 1.523 1.771 1.952	72 1.035 1.164 1.292 1.456 1.565	
73 0.112 0.123 0.127 0.156 0.185	73 0.532 0.720 0.935 1.022 1.205 1.320 1.488 1.544 1.796 1.979	73 1.050 1.180 1.310 1.477 1.587	
74 0.113 0.124 0.128 0.158 0.187	74 0.539 0.730 0.948 1.036 1.222 1.338 1.508 1.565 1.821 2.006	74 1.064 1.196 1.328 1.497 1.608	
75 0.115 0.126 0.130 0.160 0.190	75 0.546 0.740 0.961 1.050 1.238 1.356 1.528 1.586 1.845 2.033	75 1.078 1.212 1.346 1.517 1.630	
76 0.116 0.128 0.132 0.162 0.192	76 0.554 0.750 0.974 1.064 1.255 1.374 1.549 1.607 1.870 2.061	76 1.093 1.228 1.364 1.537 1.652	
77 0.118 0.129 0.134 0.164 0.195	77 0.561 0.760 0.986 1.078 1.271 1.392 1.569 1.629 1.894 2.088	77 1.107 1.244 1.382 1.557 1.674	
78 0.119 0.131 0.135 0.166 0.197	78 0.568 0.770 0.999 1.092 1.288 1.410 1.589 1.650 1.919 2.115	78 1.121 1.261 1.400 1.578 1.695	
79 0.121 0.133 0.137 0.168 0.200	79 0.575 0.780 1.012 1.106 1.304 1.428 1.610 1.671 1.944 2.142	79 1.136 1.277 1.418 1.598 1.717	
80 0.122 0.134 0.139 0.171 0.202	80 0.583 0.789 1.025 1.120 1.321 1.446 1.630 1.692 1.968 2.169	80 1.150 1.293 1.435 1.618 1.739	
81 0.124 0.136 0.141 0.173 0.205	81 0.590 0.799 1.038 1.134 1.337 1.464 1.651 1.713 1.993 2.196	81 1.165 1.309 1.453 1.638 1.761	
82 0.125 0.138 0.142 0.175 0.207	82 0.597 0.809 1.051 1.148 1.354 1.482 1.671 1.734 2.018 2.223	82 1.179 1.325 1.471 1.659 1.782	
83 0.127 0.139 0.144 0.177 0.210	83 0.604 0.819 1.063 1.162 1.370 1.500 1.691 1.756 2.042 2.250	83 1.193 1.341 1.489 1.679 1.804	
84 0.128 0.141 0.146 0.179 0.212	84 0.612 0.829 1.076 1.176 1.387 1.518 1.712 1.777 2.067 2.278	84 1.208 1.357 1.507 1.699 1.826	
85 0.130 0.143 0.148 0.181 0.215	85 [0.619] 0.839 [1.089] 1.190 [1.403] 1.536 [1.732] 1.798 [2.091] 2.305	85 1.222 1.3/4 1.525 1.719 1.848	
86 0.131 0.144 0.149 0.183 0.217	86 0.626 0.849 1.102 1.204 1.420 1.554 1.752 1.819 2.116 2.332	86 1.236 1.390 1.543 1.739 1.869	
8/ 0.133 0.146 0.151 0.185 0.220	8/ [0.634] 0.859 [1.115] 1.218 [1.436] 1.573 [1.773] 1.840 [2.141] [2.359]	8/ 1.251 1.406 1.561 1.760 1.891	
88 0.134 0.148 0.153 0.188 0.222	88 [0.641] 0.868 [1.12/] 1.232 [1.453] 1.591 [1.793] 1.861 [2.165] 2.386	88 1.265 1.422 1.5/9 1.780 1.913	
89 0.136 0.149 0.154 0.190 0.225	89 [0.648] 0.878] 1.140] 1.246] 1.469 [1.609] 1.814 [1.882] 2.190 [2.413]	89 1.280 1.438 1.597 1.800 1.934	
90 0.138 0.151 0.156 0.192 0.228	90 0.655 0.888 1.153 1.260 1.486 1.627 1.834 1.904 2.214 2.440	90 1.294 1.454 1.615 1.820 1.956	

Elite Monitor

Monitor

Calibration Chart - Imperial

Calibration Chart - Metric

Calibration Chart - Metric

Calibration Chart - Metric NWNTOS 14 MAY DDF - 5 DDF - 3 DDF - 4 LITTE DE SOL DDF -DDF. TISNED 22 25 30 28 WIS OF THEN IC DIRECT DRIVE 619 774 722 864 800 671 FERTILIZER Ciles, COARSE COARSE MEDIUM MEDIUM MEDIUM COARSE AGGREGATE CALIBRATION 20.5 - 0 - 0 - 24 MATERIAL 34 - 17 - 0 11 - 51 - 0 0 - 45 - 0 09 - 0 - 0 46 - 0 - 0 BLENDS NWNTOS NWNTOS 14 MAY 14 MAY SSD - 3 SSD - 4 DD - 6 DD - 7 DD - 8 DD - 10 SSD - 2 SSD - 5 Little Clarge DD - 5 DD - 1 DD - 2 DD - 4 DD - 9 DD - 3 Little set SSD - 1 TISNED 24 25 20 19 32 32 33 CLIFER (23 25 28 27 25 27 2 18 28 en soy 27 27 28 28 26 SLOW SPEED DRIVE THIS NIC THEN SC DIRECT DRIVE SEED & INOCULANT HI CIES HL CISS 774 722 774 774 722 568 542 580 503 645 697 800 813 903 890 335 761 800 800 735 800 671 SEED MEDIUM COARSE MEDIUM COARSE MEDIUM MEDIUM MEDIUM MEDIUM MEDIUM COARSE FINE FINE FINE FINE FINE GARBONZO BEANS LENTILS (ESTON) ADMIRAL PEAS (SMALL & MEDIUM) WINTER WHEAT -ENTILS (LAIRD) CANARY SEED FLAX SPRING WHEAT CALIBRATION CALIBRATION **PINTO BEANS** CHICK PEAS FABA BEANS SAFFLOWER NODULATOR TAG TEAM MUSTARD FALL RYE MATERIAL ALFALFA MATERIAL CLOVER CANOLA DURUM BARLEY OATS (LARGE)

Monitor

It is the policy of Morris to improve its products whenever it is possible to do so. Morris reserves the right to make changes or add improvements at any time without incurring any obligation to make such changes on machines sold previously.